

Model TW-400

TIMEX

ALARM CLOCK

WITH WIRELESS + USB CHARGING



For additional information, online registration, and exclusive special offers visit our website:
www.timexaudio.com

Questions? Contact Customer Service at 1-800-888-4491



Table of Contents	
What's in the Box	1
Controls Overview	2
Display	3
Backup Battery	3
Set Up	4
Product Care	4
Setting the Time	5
Setting and Using Alarms	6-7
Wireless Charging	6-9
Charging Devices via USB Port	10
Display Dimmer	11
Troubleshooting	12
Safety Information	13-14
Warranty Information	15

What's in the Box

This product ships with the following items. Make sure all are present.



1. TW-400 Alarm Clock (phone not included)
2. Instruction book
3. Power adapter



Set Up

Connecting to Power Source

Connect the included AC adapter to the DC jack located on the back of the unit and connect the other end to a working wall outlet.



Product Care

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.

Setting the Time

1. Press and hold the **Time Set Button** throughout the process.

2. While continuing to press and hold the **Time Set Button**, press and release the **+/- Buttons** to adjust the time.


NOTE: The PM indicator will light when the hour is set for PM. There is no AM indicator.
3. Release the **Time Set Button** to complete time setting.


Setting and Using Alarms

1. Press and hold the **Alarm Set Button** throughout the process.

2. While continuing to press and hold the **Alarm Set Button**, press and release the **+/- Buttons** to adjust the alarm time.


NOTE: The PM indicator will light when the hour is set for PM. There is no AM indicator.
3. Release the **Alarm Set Button** to complete alarm setting. The **Alarm icon** will appear on the display to confirm the alarm is armed.


Setting and Using Alarms (Continued)

RESETTING AN ALARM TO COME ON THE NEXT DAY



To silence a sounding alarm and reset it come on the next day at the same time, press and release the **Alarm Set Button**.

SNOOZING THE ALARM



Press and release the **Snooze/Dimmer Button** when the alarm sounds to silence it for 9 minutes. The alarm icon on the display will blink while the unit is in Snooze mode. Snooze can be used several times during alarm.

